


THE NEEDLE SELECTOR LS6/LS9

The Needle Selector helps you to place the desired combination of needles in the correct position on the needle bed, for various pattern stitches such as Tuck Stitch, Slip Stitch and Fair Isle.

The Needle Selector can automatically select needles in combinations or groups of 8 needles. The desired combination is set ready by hand over the first group and slide the Selector across the needles.


The Needle Selector does not knit. It pushes the selected needles to C position by sliding it across the needles in B and C position.



HOW TO USE THE NEEDLE SELECTOR


Let us try a few examples to make the explanations easier to follow. At the beginning, we will try an example without knitting.

1. Push the required number of needles to B position.
2. Place the Needle Selector onto the needle bed on the right side of the needles in B position as shown below.




* Fit the groove ① of the Selector to the rear rail of the needle bed.

3. Leave the first 2 needles from the right in B position, push the third and fourth needles to C position by hand, again leave 2 needles in B position and push 2 needles to C position by hand, as shown below.




REMEMBER: The Selector only select needles in combinations or groups of 8 needles.


4. Slide the Selector across the needles in B and C position towards the left.



REMEMBER: The Selector only works from the right side of the machine to the left side.


5. The 2 needles in B position and the 2 needles in C position make a combination of 4 needles.






■....Push the needle to C position.


- as shown below.




3. Place the Selector onto the needle bed on the right side of the needles in B and C position and slide it across the needles towards the left.



N.B. While sliding the Selector, push the knitting against the machine by hand to hold it firmly in position.



4. Push the needles in C position to D position using the straight side of Needle Pusher.



5. Knit 2 rows in Tuck Stitch.

N.B. In case of knitting on LK 140 or LK 150, set both Side Levers to ▲ and Russel Levers to I.

6. Knit 1 row in Stockinet.

N.B. In case of knitting on LK 100, push the needles in D position back to C position.

In case of knitting on LK 140 or LK 150, set the Russel Lever on the side next to the knitting to II.

7. Repeat steps 2 ~ 6.